



SuperDos 45 Quick Start Guide

0.25 - 45 gpm 5 – 100 psi*

57 - 10000 l/h 0,4 – 6,9 bar*

***5% model has maximum operating pressure of 80 psi (5,5 bar)**

*****NOTE*** Remote injection is NOT recommended for use with the 5% model**




SuperDos 45 Quick Start Guide

0.25 - 45 gpm 5 – 100 psi*

57 - 10000 l/h 0,4 – 6,9 bar*

***5% model has maximum operating pressure of 80 psi (5,5 bar)**

*****NOTE*** Remote injection is NOT recommended for use with the 5% model**



SuperDos 45 Quick Start Guide

0.25 - 45 gpm 5 – 100 psi*

57 - 10000 l/h 0,4 – 6,9 bar*

***5% model has maximum operating pressure of 80 psi (5,5 bar)**

*****NOTE*** Remote injection is NOT recommended for use with the 5% model**



